

C The Router's Web-based Utility will appear with the *Basic Setup* screen showing.

D For the Internet Connection Type setting, six Internet connection types are offered through the drop-down menu. Depending on which connection type you select, the features available on the *Basic Setup* screen will differ. Proceed to the instructions for the connection type you are using.

1 Obtain an IP Automatically (DHCP)

a If your ISP says that you are connecting through DHCP or a dynamic IP address from your ISP, then select **Obtain an IP automatically** as the Internet Connection Type.

b Click the **Save Settings** button.

2 Static IP

a If your ISP says that you are connecting through a static or fixed IP address from your ISP, then select **Static IP** as the Internet Connection Type.

b Enter the IP Address, Subnet Mask, and Gateway Address provided by your ISP.



Obtain an IP Automatically

Static IP

IP Address: 0 . 0 . 0 . 0

Subnet Mask: 255 . 255 . 255 . 0

Default Gateway: 0 . 0 . 0 . 0

DNS 1: 0 . 0 . 0 . 0

DNS 2: 0 . 0 . 0 . 0

DNS 3: 0 . 0 . 0 . 0

Static IP

c In the *DNS 1-3* fields, enter the DNS address(es) provided by your ISP. You need to enter at least one DNS address.

d Click the **Save Settings** button.

3 PPPoE

a If your ISP says that you are connecting through PPPoE or if you normally enter a user name and password to access the Internet, then select **PPPoE** as the Internet Connection Type.

b Enter the User Name and Password provided by your ISP. (Also enter the Service Name, if required.)

c Select **Keep Alive** if you always want to be connected to your ISP, or select **Connect on Demand** if you are charged for the time that you are connected to your ISP.

d Click the **Save Settings** button.

e Click the **Status** tab and then the **Router** tab. Click the **Connect** button to start the connection.

PPPoE

User Name: _____

Password: _____

Service Name: _____

Connect on Demand: Max Idle Time 5 Min.

Keep Alive: Redial Period 30 Sec.

PPPoE

4 PPTP

PPTP is a service used in Europe and Israel only. If you are using a PPTP connection, check with your ISP for the necessary setup information.

5 RAS

RAS is a service used in Singapore only. If you are using a RAS connection, check with your ISP for the necessary setup information.

6 Heart Beat Signal

Heart Beat Signal is a service used in Australia only. If you are using a Heart Beat Signal connection, check with your ISP for the necessary setup information.

E If requested by your ISP (usually cable ISPs), complete the *Host Name* and *Domain Name* fields. Otherwise, leave them blank.

F If you haven't already done so, click the **Save Settings** button. Then close the web browser.

G Power your cable or DSL modem off and back on again.

H Restart or power on your PCs so they can obtain the Router's new settings.

PPTP

IP Address: 0 . 0 . 0 . 0

Subnet Mask: 255 . 255 . 255 . 0

Default Gateway: 0 . 0 . 0 . 0

User Name: _____

Password: _____

Connect on Demand: Max Idle Time 5 Min.

Keep Alive: Redial Period 30 Sec.

PPTP

RAS (for SingTel)

User Name: _____

Password: _____

RAS Plan: 512k Ethernet

Connect on Demand: Max Idle Time 5 Min.

Keep Alive: Redial Period 30 Sec.

RAS

Heart Beat Signal

User Name: _____

Password: _____

Heart Beat Server: 0 . 0 . 0 . 0

Connect on Demand: Max Idle Time 5 Min.

Keep Alive: Redial Period 30 Sec.

Heart Beat Signal

To test the Router's settings, open your web browser from any computer. In the browser's *Address* field, enter www.linksys.com/registration and press the **Enter** key.

Congratulations! The installation of the Router is complete.

NOTE: If your Internet phone service provider sent you the Router, then it may be pre-configured for you, and you do not need to change any settings. If you wish to make changes, refer to the instructions supplied by your Internet phone service provider.

If you need to manually configure the Router's Internet phone service settings, then refer to the User Guide on the Setup CD.

Address <http://www.linksys.com/registration/>



For additional information or troubleshooting help, refer to the User Guide on the Setup CD-ROM. You can also call or e-mail for further support.

- 24-hour Technical Support**
800-326-7114
(toll-free from US or Canada)
- E-mail Support**
support@linksys.com
- Website**
<http://www.linksys.com> or
<http://support.linksys.com>
- RMA (Return Merchandise Authorization)**
<http://www.linksys.com/support>
- FTP Site**
<ftp://ftp.linksys.com>
- Sales Information**
800-546-5797 (800-LINKSYS)

Linksys is a registered trademark or trademark of Cisco Systems, Inc. and/or its affiliates in the U.S. and certain other countries. Copyright © 2004 Cisco Systems, Inc. All rights reserved.